

# Used Products

TOOTH - Crown - Oxide ceramics - Non-retentive preparation - Multilink Automix

**Multilink Automix**

The universal self-curing luting composite with optional light-curing



**Proxyl fluoride-free**

Prophy paste without fluoride



**OptraStick**

Application instrument that features a flexible adhesive tip



**Ivoclean**

The universal cleaning paste Ivoclean effectively cleans the bonding surfaces of prosthetic restorations after intraoral try-in



**Monobond Plus**

Monobond Plus is the universal primer for the conditioning of all types of restoration surfaces



**OptraDam**

Anatomically shaped rubber dam for the absolute isolation of the working field



**Liquid Strip**

Glycerine gel to prevent the oxygen-inhibited layer of composites with composite or ceramic restorations



**OptraPol**

OptraPol is excellently suitable for finishing and polishing all popular composite materials in a single step



**Fluor Protector**

Fluor Protector is a protective fluoride varnish for desensitization and caries prophylaxis



# Flowchart Multilink Automix


TOOTH - Crown - Oxide ceramics - Non-retentive preparation - Multilink Automix

## 1 The temporary is removed



The temporary is removed. If necessary, any leftover temporary cement is removed from the preparation with a polishing brush and cleaning paste free of oil and fluoride (e.g. **Proxyt fluoride-free**). Subsequently, the preparation is dried with moisture-free and oil-free air.

## 2 The restoration is tried in



The permanent restoration is tried in. At this stage, the shade, accuracy of fit and occlusion of the restoration are checked.

## 3 The restoration is pretreated



The inner surfaces of the restoration are sandblasted (e.g. **IPS e.max ZirCAD**, 1 bar, Al<sub>2</sub>O<sub>3</sub> 100 µm or as directed by the manufacturer of the restorative materials).



**Monobond Plus** is applied to the pretreated surfaces with a brush or microbrush and left to react for 60 seconds. Subsequently, it is dried with a vigorous stream of air.

**4** The preparation is isolated and cleaned



Relative isolation of the treatment field - preferably with **OptraDam** or alternatively with absorbent pads and a saliva ejector - is indispensable.




The preparation is cleaned with a polishing brush and moisture-free and fluoride-free cleaning paste (e.g. **Proxyl fluoride-free**). Then it is rinsed with water spray. Subsequently, it is dried with air free of oil and moisture. Overdrying must be avoided.

**5** Multilink Primer A/B and Multilink Automix are applied



Apply the mixed Multilink Primer A/B onto the entire bonding surface using a microbrush, starting with the enamel surface, and scrub it in for 30 sec.



Excess **Multilink Primer** is dispersed with a strong stream of air until the mobile film disappears. As the primer is self-curing, light-curing is unnecessary!




**Multilink Automix** is dispensed from the automix syringe and the desired amount is applied directly to the restoration.


**6** The restoration is seated and excess cement is removed



The restoration is seated and held in place using light constant pressure.



Light-cure excess cement in quarter segments (mesio-oral, disto-oral, mesio-buccal, disto-buccal) using a polymerization light at a distance of max. 10 mm.




Light intensity approx. 650 mW/cm<sup>2</sup>: 3 sec Exposure time per quarter segment - e.g. **Bluephase** in LOW POWER mode  
 Light intensity approx. 1,000 mW/cm<sup>2</sup>: 1-2 sec Exposure time per quarter segment - e.g. **Bluephase Style** or **Bluephase** in HIGH POWER mode



The gel-like excess material can be easily removed with a scaler.



Like all composites, **Multilink Automix** is subject to oxygen inhibition. In order to avoid this problem, it is advisable to cover the restoration margins with glycerine gel/air block (e.g. **Liquid Strip**) immediately after the removal of excess cement.




Subsequently all the cement margins are light cured for another 20 seconds (approx. 1,100 mW/cm<sup>2</sup>). Materials that are opaque, in other words, impervious to light, should be allowed to self-cure.



**Liquid Strip** is rinsed off and the rubber dam is removed.

**7** The completed restoration is finished



Proximal areas are adjusted with finishing and polishing strips. The occlusion and functional movements are checked and adjusted if necessary. The restoration margins are polished with polishers (e.g. **OptraPol**) or discs.

**8** The teeth are fluoridated



A thin film of **Fluor Protector** is applied with a Vivabrush or brush and distributed evenly. The varnish is dried with an air syringe.