

Used Products

TOOTH - Root post - Zirconium oxide ceramics - Multilink N

☐ **Multilink N**

El cemento autoadhesivo, autopolimerizable con opción de fotopolimerización



☐ **OptraDam**

Anatomically shaped rubber dam for the absolute isolation of the working field



☐ **N-Etch**

N-Etch is an etching gel containing 37% phosphoric acid



☐ **Monobond N**

Monobond N is the universal primer for the conditioning of all types of restoration surfaces



☐ **MultiCore**


Core build-up in vital and non-vital teeth



Flowchart Multilink N

TOOTH - Root post - Zirconium oxide ceramics - Multilink N

1 Preoperative situation




Relative isolation of the treatment field - preferably with **OptraDam** or alternatively with absorbent pads and a saliva ejector - is indispensable.

2 The root post is tried in




The root post is tried in. If prefabricated posts are used, the excess length is determined and the post is shortened extraorally by means of rotating diamond grinding instruments.

3 The root post is pretreated




After try-in, the post is cleaned with alcohol or conditioned as directed by the manufacturer.




Monobond N is applied to the post with a brush or microbrush. It is allowed to react for 60 seconds. Subsequently, it is dispersed with a strong stream of air

4 The conditioned root canal is disinfected




Finally, the conditioned root canal is disinfected and dried with paper points.

5 Multilink N Primer A/B and Multilink N are applied



The mixed **Multilink N Primer A/B** is applied to the root canal and the occlusal surface of the prepared tooth with a fine microbrush (Vivadent Applicator Small) for about 15 seconds. Excess is removed from the canal with paper points.



The root post prepared according to the instructions of the manufacturer is coated with the mixed **Multilink N**.


6 The root post is seated



The endodontic post is inserted, thus forcing out excess cement.




The cement can be distributed across the entire preparation surface for total coverage. Then **Multilink N** is light-cured for 20 sec. During this time, the post is held in place with the polymerization unit.



Materials that are opaque, in other words, impervious to light, should be allowed to self-cure. **Multilink N** serves as a bonding agent to the core build-up material.

7 Core build-up



The core build-up material (e.g. **MultiCore Flow**) is filled in the core coping. Subsequently, a small amount of the core build-up material is applied directly to Multilink N. The core coping is placed on the prepared tooth.

The core build-up material is cured according to the directions of the manufacturer.

8 Core build-up is prepared in accordance with a ferrule design



The core coping is removed and the the core build-up is prepared in accordance with a ferrule design.